

Computational Electrodynamics

The Finite-Difference Time-Domain Method

Allen Taflove



Artech House
Boston • London

Contents

Preface	xv
Chapter 1 Reinventing Electromagnetics	1
1.1 Background	1
1.1.1 The Heritage of the 1980s	1
1.1.2 The Rise of Partial Differential Equation Methods	3
1.1.3 Interdisciplinary Impact of Emerging Time-Domain PDE Solvers	4
1.2 History of Space-Grid Time-Domain Techniques for Maxwell's Equations	4
1.3 General Characteristics of Space-Grid Time-Domain Approaches	6
1.3.1 Classes of FD-TD and FV-TD Algorithms	7
1.3.2 Predictive Dynamic Range	8
1.4 Scaling to Very Large Problem Sizes	9
1.4.1 Algorithm Scaling Factors	9
1.4.2 Computer Architecture Scaling Factors	10
1.5 Defense Applications	11
1.5.1 RCS Modeling of Entire Aircraft to 1 GHz	11
1.5.2 Desirable Additional Modeling Capabilities for Defense Applications	11
1.6 Dual-Use Electromagnetics Technology	14
1.6.1 Antenna Design	14
1.6.2 Bioelectromagnetic Systems 1: Hyperthermia Treatment of Cancer	23
1.6.3 Bioelectromagnetic Systems 2: Physics of Human Vision	23
1.6.4 Digital Circuit Packaging and Interconnects	24
1.6.5 Incorporation of Models of Active Circuit Devices	25
1.6.6 Subpicosecond Photonic Devices	27
1.7 Conclusions	29
Supplemental Reading	29
References	30
Chapter 2 The One-Dimensional Scalar Wave Equation	35
2.1 Introduction	35
2.2 Propagating-Wave Solutions	35
2.3 Finite Differences	36
2.4 Finite-Difference Approximation of the Scalar Wave Equation	38
2.5 Dispersion Relations for the One-Dimensional Wave Equation	40
2.6 Numerical Phase Velocity	42
2.6.1 Case 1: Very Fine Mesh	43
2.6.2 Case 2: Magic Time Step	43
2.6.3 Case 3: Dispersive Wave Propagation	44
2.7 Numerical Group Velocity	45
2.7.1 Case 1: Very Fine Mesh	45
2.7.2 Case 2: Magic Time Step	46
2.8 Numerical Stability	46
2.8.1 The Time Eigenvalue Problem	47
2.8.2 The Space Eigenvalue Problem	48
2.8.3 Enforcement of Stability	49
Problems	50

Chapter 3	Introduction to Maxwell's Equations and the Yee Algorithm	51
3.1	Introduction	51
3.2	Maxwell's Equations in Three Dimensions	51
3.3	Reduction to Two Dimensions	54
3.3.1	TM Mode	55
3.3.2	TE Mode	55
3.4	Reduction to One Dimension	56
3.4.1	TM Mode	56
3.4.2	TE Mode	57
3.5	Equivalence to the Wave Equation in One Dimension	57
3.6	The Yee Algorithm	59
3.6.1	Basic Ideas	59
3.6.2	Finite Differences and Notation	61
3.6.3	Finite-Difference Expressions for Maxwell's Equations in Three Dimensions	64
3.6.4	Space Region with a Continuous Variation of Material Properties	67
3.6.5	Space Region with a Finite Number of Distinct Media	68
3.6.6	Space Region with Nonpermeable Media	70
3.6.7	Reduction to the Two-Dimensional TM and TE Modes	71
3.6.8	Interpretation as Faraday's and Ampere's Laws in Integral Form	72
3.6.9	Divergence-Free Nature	76
3.6.10	Exponential Time-Stepping	77
	References	79
	Problems	79
Chapter 4	Numerical Stability	81
4.1	Introduction	81
4.2	Basic Stability Analysis Procedure, TM Mode	82
4.3	Time Eigenvalue Problem	83
4.4	Space Eigenvalue Problem	85
4.5	Enforcement of Stability	87
4.6	Extension to the Full Three-Dimensional Yee Algorithm	88
4.7	Generalized Stability Problem	90
4.7.1	Boundary Conditions	90
4.7.2	Variable and Unstructured Meshing	91
4.7.3	Lossy, Dispersive, Nonlinear, and Gain Materials	91
	Reference	92
	Bibliography on Stability of Finite-Difference Methods	92
	Problems	92
Chapter 5	Numerical Dispersion	93
5.1	Introduction	93
5.2	Basic Procedure	94
5.3	Substitution of Traveling-Wave Trial Solutions	95
5.4	Extension to the Full Three-Dimensional Yee Algorithm	96
5.5	Comparison with the Ideal Dispersion Case	97
5.6	Reduction to the Ideal Dispersion Case for Special Grid Conditions	101
5.7	Dispersion-Optimized Basic Yee Algorithm	101
5.8	Dispersion-Optimized Yee Algorithm with Fourth-Order Accurate Spatial Central Differences	102
5.8.1	Formulation	102

5.8.2	Example	103
5.8.3	Pros and Cons	104
	Problems	105

Chapter 6 Incident Wave Source Conditions for Free Space and Waveguides **107**

6.1	Introduction	107
6.2	Requirements for the Plane Wave Source Condition	108
6.3	Insertion of the Incident Wave As an Initial Condition	108
6.4	The Hard Source	109
6.5	Total-Field/Scattered-Field Formulation	111
6.5.1	Ideas	111
6.5.2	One-Dimensional Example	114
6.5.3	Two-Dimensional Example	117
6.5.4	Calculation of the Incident Field to Implement the Connecting Condition	121
6.5.5	Extension to Three Dimensions	126
6.6	Pure Scattered-Field Formulation	135
6.6.1	Application to PEC Structures	135
6.6.2	Application to Lossy Dielectric Structures	136
6.7	Choice of Incident Plane Wave Formulation	137
6.8	Waveguide Source Conditions	138
6.8.1	Pulsed Electric Field Hard Source	138
6.8.2	Total-Field/Reflected-Field Formulation	140
6.8.3	Resistive Source and Load Conditions	141
	References	142
	Problems	142

Chapter 7 Absorbing Boundary Conditions for Free Space and Waveguides **145**

7.1	Introduction	145
7.2	Bayliss-Turkel Scattered-Wave Annihilating Operators	147
7.2.1	Spherical Coordinates	148
7.2.2	Cylindrical Coordinates	151
7.3	Engquist-Majda One-Way Wave Equations	153
7.3.1	One-Term and Two-Term Taylor Series Approximations	154
7.3.2	Mur Finite-Difference Scheme	158
7.3.3	Trefethen-Halpern Generalized and Higher-Order ABCs	160
7.3.4	Theoretical Reflection Coefficient Analysis	163
7.3.5	Numerical Experiments	165
7.4	Higdon Operator	171
7.5	Liao Extrapolation	174
7.6	Mei-Fang Superabsorption	178
7.7	Berenger Perfectly Matched Layer	181
7.7.1	Theory, Two-Dimensional TE Case	182
7.7.2	Theory, Two-Dimensional TM Case	188
7.7.3	Theory, Full-Vector Three-Dimensional Case	189
7.7.4	Numerical Experiments Verifying the Effectiveness of PML ABC	190
7.8	Absorbing Boundary Conditions for Waveguides	195
	References	198
	Problems	201

Chapter 8 Near-to-Far-Field Transformation	203
8.1 Introduction	203
8.2 Two-Dimensional Transformation, Phasor Domain	204
8.2.1 Application of Green's Theorem	205
8.2.2 Far-Field Limit	206
8.2.3 Reduction to Standard Form	208
8.3 Obtaining Phasor Quantities Via Discrete Fourier Transformation	210
8.4 Surface Equivalence Theorem	213
8.5 Extension to Three Dimensions, Phasor Domain	215
8.6 Time-Domain Near-to-Far-Field Transformation	219
References	224
Problems	225
Chapter 9 Dispersive, Nonlinear, and Gain Materials	227
9.1 Introduction	227
9.2 Recursive Convolution Method, Linear Isotropic Case	228
9.2.1 Total-Field Formulation	228
9.2.2 Scattered-Field Formulation	233
9.2.3 Discussion	237
9.3 Recursive Convolution Method, Linear Gyrotropic Case	237
9.3.1 Time-Domain Susceptibility Functions	239
9.3.2 Time-Stepping Algorithm	240
9.3.3 Discussion	246
9.4 Auxiliary Differential Equation Method, Linear Isotropic Case	246
9.4.1 Introduction: The Single-Relaxation Dispersion, Initial Formulation	246
9.4.2 Multiple Lorentzian Relaxations, Refined Formulation	251
9.4.3 Comparison with the Recursive Convolution Method	254
9.5 Auxiliary Differential Equation Method, Nonlinear Lorentz Media (Nonlinear Optics)	257
9.5.1 Governing Equations	258
9.5.2 Equivalent System of Ordinary Differential Equations	259
9.5.3 Algorithm	261
9.5.4 Results for Temporal Solitons	263
9.5.5 Results for Spatial Solitons	266
9.5.6 Discussion	269
9.6 Auxiliary Differential Equation Method, Lorentz Gain Media (Active Lasing Materials)	270
9.6.1 Theory and Numerical Implementation	270
9.6.2 Generic Validations	274
9.6.3 Discussion	274
References	274
Problems	278
Chapter 10 Local Subcell Models of Fine Geometrical Features	281
10.1 Introduction	281
10.2 Basis of Contour-Path FD-TD Modeling	282
10.3 The Simplest Contour-Path Subcell Models	283
10.3.1 Diagonal Split-Cell Model for PEC Surfaces	283
10.3.2 Average Properties Model for Material Surfaces	285
10.4 The Contour-Path Model of the Narrow Slot	286
10.5 The Thin Wire	288

10.6	Conformal Modeling of Curved Surfaces	292
10.6.1	Two-Dimensional PEC Structures, TE Case	292
10.6.2	Two-Dimensional PEC Structures, TM Case	296
10.6.3	Illustrative Results, Aluminum Winglike Object	296
10.6.4	Three-Dimensional PEC Structures	298
10.6.5	Two-Dimensional Material Structures	300
10.7	The Thin Material Sheet	304
10.7.1	Basis	304
10.7.2	Illustrative Results	309
10.8	Dispersive Surface Impedance	312
10.8.1	Maloney-Smith Method	314
10.8.2	Beggs et al. Method	320
10.8.3	Lee et al. Method	327
10.9	Relativistic Motion of PEC Boundaries	331
10.9.1	Basis	331
10.9.2	Illustrative Results	335
10.10	Numerical Stability	338
	References	338
	Additional Bibliography	341
	Problems	342
Chapter 11 Explicit Time-Domain Solution of Maxwell's Equations Using Nonorthogonal and Unstructured Grids		343
11.1	Introduction	343
11.2	Nonuniform Orthogonal Grids	344
11.3	Locally Conformal Grids, Globally Orthogonal	353
11.4	Global Curvilinear Coordinates	353
11.4.1	Nonorthogonal Curvilinear FD-TD Algorithm	353
11.4.2	Stability Criterion	359
11.5	Irregular Nonorthogonal Structured Grids	361
11.6	Irregular Nonorthogonal Unstructured Grids	368
11.6.1	Generalized Yee Algorithm	369
11.6.2	Inhomogeneous Media	374
11.6.3	Practical Implementation of the Generalized Yee Algorithm	376
11.7	A Planar Generalized Yee Algorithm	377
11.7.1	Time-Stepping Expressions	379
11.7.2	Projection Operators	380
11.7.3	Efficient Time-Stepping Implementation	381
11.8	Analysis of Printed Circuit Devices Using the Planar Generalized Yee Algorithm	382
	References	390
	Problems	393
Chapter 12 The Body of Revolution FD-TD Algorithm		397
12.1	Introduction	397
12.2	Field Expansion	398
12.3	Difference Equations for Off-Axis Cells	398
12.3.1	The e_r Patch Integral	400
12.3.2	The e_ϕ Patch Integral	402
12.3.3	The e_z Patch Integral	404
12.3.4	Difference Equations	407

12.3.5 Surface-Conforming Patch Integrals	410
12.4 Difference Equations for On-Axis Cells	412
12.4.1 The e_z Patch Integral Near the Axis	412
12.4.2 The e_ϕ Patch Integral Near the Axis	414
12.4.3 The h_r Patch Integral Near the Axis	416
12.5 Numerical Stability	417
12.6 PML Absorbing Boundary Condition	417
12.6.1 BOR FD-TD Background	417
12.6.2 Extension of PML to the BOR Waveguide Case	420
12.6.3 Examples	421
12.7 Application to Particle Accelerator Physics	423
12.7.1 Definitions and Concepts	423
12.7.2 Examples	426
References	429
Problems	430
Chapter 13 Modeling of Electromagnetic Fields in High-Speed Electronic Circuits	431
13.1 Introduction	431
13.2 Basic Circuit Parameters	432
13.2.1 Transmission Line Parameters	432
13.2.2 Impedance	433
13.2.3 S-Parameters	434
13.3 Differential Capacitance Calculation	434
13.4 Differential Inductance Calculation	435
13.5 Lumped Inductance Due to a Discontinuity	437
13.5.1 Flux/Current Definition	437
13.5.2 Fitting $Z(\omega)$ or $S_{mn}(\omega)$ to an Equivalent Circuit	438
13.5.3 Discussion: Choice of Methods	439
13.6 Parallel Coplanar Microstrips	439
13.7 Multilayered Interconnect Modeling Example	440
13.8 Digital Signal Processing and Spectrum Estimation Techniques	442
13.8.1 Prony's Method	443
13.8.2 Autoregressive Models	447
13.8.3 System Identification	453
13.9 Modeling of Lumped Circuit Elements	456
13.9.1 FD-TD Formulation Extended to Circuit Elements	456
13.9.2 The Resistor	458
13.9.3 The Resistive Voltage Source	459
13.9.4 The Capacitor	459
13.9.5 The Inductor	460
13.9.6 The Diode	461
13.9.7 The Bipolar Junction Transistor	463
13.10 Direct Linking of FD-TD and SPICE	465
References	470
Additional Bibliography	472
Problems	473

Chapter 14 FD-TD and Antenna Analysis	475
14.1 Introduction	475
14.2 Antenna Characteristics	477
14.2.1 Antenna Fields and Radiation Patterns	477
14.2.2 Antenna Impedance	479
14.3 Motivation for Using FD-TD in Antenna Design	479
14.4 The Monopole Over a PEC Ground Plane	480
14.4.1 Modeling Considerations	480
14.4.2 Results	482
14.4.3 Discussion	483
14.5 Waveguide and Horn Antennas	487
14.5.1 Two-Dimensional Horn Antenna	487
14.5.2 Three-Dimensional Waveguide Radiator	489
14.5.3 Discussion	490
14.6 The Vivaldi Slotline Array	491
14.6.1 Background	491
14.6.2 The Planar Element	493
14.6.3 The Two-Element Vivaldi Pair	496
14.6.4 The Quad Element	498
14.6.5 The Linear Phased Array	498
14.6.6 Active Impedance of the Phased Array	503
14.7 Linear Superposition	506
References	507
Bibliography	509
Projects	510
Chapter 15 Electromagnetic Wave Scattering, Penetration, and Coupling for Complex Structures	511
15.1 Introduction	511
15.2 Scattering and Radar Cross Section	512
15.2.1 Small PEC Cube, Broadside Incidence	512
15.2.2 Nine-Wavelength T-Shaped Conducting Target	514
15.2.3 Generic Curved-Surface Targets, Conformally Modeled	515
15.2.4 Full-Scale Military Fighter Aircraft	516
15.3 Penetration and Coupling	517
15.3.1 Empty Cylindrical PEC Cavity	517
15.3.2 Loaded Missile Guidance Section	518
15.3.3 Spatial Decomposition via a Schelkunoff Equivalence Principle	522
15.3.4 Cylindrical PEC Cavity Loaded by a Wire Bundle	525
15.4 Biological Tissue Structures	529
15.4.1 The First FD-TD Biological Tissue Model: The Human Eye	530
15.4.2 Patient-Specific Electromagnetic Hyperthermia Models Derived from Computed Tomography Imaging and Analysis	530
15.4.3 Visible Light Interactions with the Vertebrate Retinal Rod	535
15.5 Microlaser Cavities	538
References	541
Bibliography	543

Chapter 16 Efficient FD-TD Algorithms for Vector and Multiprocessor Computers	545
16.1 Introduction	545
16.2 Pipelined RISC and Vector Processors	546
16.3 Multiprocessor Computers	551
16.3.1 Introduction to Parallelism	551
16.3.2 Parallel FD-TD Algorithm	555
16.3.3 Numerical Benchmarks	558
16.4 Parallel Nonorthogonal FD-TD Algorithms	560
16.5 Parallel Planar Generalized Yee Algorithm	561
16.5.1 The Parallel Algorithm	561
16.5.2 Spatial Decomposition Algorithms	564
16.6 Porting FDTD3D to the Cray T3D	570
16.6.1 Background	570
16.6.2 T3D Programming Models	570
16.6.3 Program Design Issues	572
16.6.4 Single-Processor Optimization	576
16.6.5 Performance	579
References	581
Problems	583
Author and Citation Index	585
Subject Index	591
About the Chapter Authors	597