

Inhaltsverzeichnis

Vorwort	7
Plattenspieler, Tonbandgeräte und Kassettenrekorder	9
Geschichte und Technik	9
Die Fünfziger-Jahre	14
1950	14
1951	15
1952	15
1953	16
1954	16
1955	17
1956	18
1957	19
1958	21
1959	22
Die Sechziger-Jahre	23
1960	23
1961	27
1962	28
1963	31
1964	33
1965	35
1966	39
1967	41
1968	44
1969	47

Die Siebziger-Jahre	50
1970	50
1971	53
1972	55
1973	57
1974	59
1975	60
1976	61
1977	61
1978	63
1979	64
Die Achtziger-Jahre	66
1980	66
1981	68
1982	70
1983	71
1984	72
1985	73
1986	74
1987	75
1988	76
1989	77
Die Neunziger-Jahre	78
1990	78
1991	78
1992	79
1993	79
1994	80
1995	81
1996	81
1997	81
1998	82
1999	83
2000	83
Selbstbau	86
RIAA-Entzerrer	86
Impedanzwandler	87
Sinusgenerator	87
Netzgerät mit einstellbarer Ausgangsspannung	87
Restaurierung	89